

**DURABLE • RE-USABLE • WATERPROOF • CHEMICAL RESISTANT**

## SOME HELPFUL TIPS...

- Fittings should be installed first, with Drip Edges facing down.
- On horizontal runs, straight lengths should be installed with the hinged side facing up and the seam opening facing down.
- Band every foot on straights, making sure that there is a band on the Buttstrip end where straights connect to fittings.

**...REMEMBER, ORIENTATION MATTERS!**

## MODIFYING STRAIGHTS

- Always cut the opposing end from the Buttstrip.
- Use a Sawzall, Hand Saw, or cutting tool with fine toothed metal blade to make cuts.
- Caulk the Splice Cover to the cut end of the straight.

## RECOMMENDED SUPPLIES

- Cutting Tool (For best results use Sawzall, Handsaw, or cutting tool with fine toothed metal blade)
- Stainless Steel Bands
- Banding Tool
- Caulking or equivalent
  - Dry Areas: PL Polyurethane Sealant Loctite Roof and Flashing
  - Wet Areas: 3M Marine Adhesive Sealant 5200

## TRAINING VIDEOS

The DRAGON JACKET INSULATION™ INSTALLATION TRAINING SERIES offers videos demonstrating installations and field modifications.

**YOUTUBE CHANNEL:** [https://www.youtube.com/channel/UCboOv\\_5iSS65mE8\\_-pjcJxQ](https://www.youtube.com/channel/UCboOv_5iSS65mE8_-pjcJxQ)

**WEBSITE:** <http://dragonjacket.com/>

