

INSTALLING DRAGON JACKET INSULATION

Enclosed is a Dragon Jacket Flash Drive with videos demonstrating installations, such as a Tee and Straight installation, and a video showing how to modify a Straight and install the Splice Cover.

Some Helpful Tips

- Fittings need to be installed first with the drip edge facing down.
- On horizontal runs, straight lengths are installed with the hinge side up with the seam opening facing down.
- Band with Stainless Steel bands every foot on straights, making sure that there is a band on the Buttstrip end where Straights connect to Fittings.



Modifying Straights

- Always cut the opposing end from the Buttstrip. Use a Sawzall, Handsaw, or cutting tool with fine toothed metal blade to cut the material.
- Caulk the Splice Cover to the cut end of the straight.

Recommended Supplies

- Cutting Tool (For best results use Sawzall, Handsaw, or cutting tool with fine toothed metal blade)
- Stainless Steel Bands
- Banding Tool
- Caulking or equivalent
 - For dry areas use PL Polyurethane Sealant Loctite Roof and Flashing
 - For wet areas use 3M Marine Adhesive Sealant 5200



For further installation support go to dragonjacket.com or our YouTube Channel to view installation videos or call (208) 772-8640.

YouTube: https://www.youtube.com/channel/UCboOv_5iSS65mE8_-pjcJxQ

Website: <http://dragonjacket.com/>